

MDM PROPORTIONAL PRESSURE-REDUCING VALVE


Electrical operation

Series MDM-5 Size 5









FEATURES

- * Pressure reducing over the whole range independent of the supply pressure.
- * Several sub-plates available.
- * Conversion to ISO/CETOP mounting surface.
- * Several control pressure ranges available.
- * Different pressure ranges for the two pilot lines possible.
- * Proportional solenoids with longer life for the armature in the oil.
- * Several types of proportional solenoids, such as explosion proof "II 2 G EEx m II T4" and IP67.
- * Adjustable valve response time.

TECHNICAL DATA

- maximum operating pressure conn. P
- maximum return pressure conn. T
- pressure range conn. A and B
- flow range
- viscosity range
- contamination level max.
- ambient temperature
- mounting position
- fluid
- mounting surface roughness
- mounting surface flatness
- nominal voltage
- nominal current
- valve response time
- hysteresis
- resolution
- continuous operation
- seals
- recommended dither frequency

- 350 bar (5000 psi)
- 15 bar (215 psi)
- 0 12 bar (0- 172 psi) 0 70 bar (0-1000 psi)
- 0 190 bar (0-2717 psi) or 0 350 bar (0-5000 psi)
- or 0 - 120 bar (0-1716 psi)

or

- 6 l/min (1.6 USgpm) with 32 cSt and Δp = 30 bar (429 psi)

0 - 30 bar (0- 429 psi)

- 2,8 380 cSt
- NAS 1638 class 9 or ISO 18/15
- -35°C to +80°C (-31°F to 176°F)
- any
- mineral oil; other media on request
- N6 (0,8 μm) according to ISO 468 and ISO 1302.
- 0,01 mm over a distance of 100 mm according to ISO 1101.
- 12 V DC, 24 V DC
- see diagrams Fig. 1 and 2
- adjustable: ± 0,08 10 seconds
- < 3% (with dither)
- < 0,5% (with dither)
- 100%
- std. BUNA-N, optional Viton
- 100 Hz

DIAGRAMS




Fig. 1 DUAL TYPE




Fig. 2 SINGLE TYPE

ORDERING CODE MDM 5 **DUAL TYPE** MDM - 5 - 70 - 190 - B / Viton SERIES MDM-5 CONTROL PRESSURE RANGE, DUAL TYPE: Port A in bar *: 12, 30, 70, 120, 190 or 350 bar Example: MDM-5-70-70/B CONTROL PRESSURE RANGE. * only in code for dual type Port B in bar: 12, 30, 70, 120, 190 or 350 bar SINGLE TYPE SOLENOID TYPE A = 12V DC IP65 with emergency control by pin B = 24V DC IP65 with emergency control by pin E = 12V DC IP65 with emergency control by button F = 24V DC IP65 with emergency control by button H = 24V DC IP57 II 2 G EEx m II T4 (Explosion Proof) J = 24V DC IP67, without female connector Example: MDM-5-350/B **OPTIONS** Viton = With Viton seals SUB-PLATE A-5-DM - 3 / Viton SUBPLATE (a)" (a)" (a)" SERIES A-5-DM = Sub-plate NUMBER 1-8 = choose number of MDM-5 valve which has to be mounted on one subplate (up to 8) OPTIONS SAE = S.A.E. straight thread 'O'RING BOSS Viton = With Viton seals CONVERSION PLATE CONVERSION PLATE A-5-PS / Viton SERIES A-5-PS = Conversion to ISO/CETOP 3 model **OPTIONS** Viton = With Viton seals RECOMMENDED SPARE PARTS

R - ... - 016 06 ASSEMBLY KIT:SEALS (BUNA-N) AND SCREWS

R SPARE KIT

01 SEALS (BUNA-N)

11 SEALS (VITON)

SOLENOID, incl. bolts and seal 8WX-2170-002 = 12V DC IP65 with emergency control by pin 8WX-2170-001 = 24V DC IP65 with emergency control by pin 8WX-2170-012 = 12V DC IP65 with emergency control by button 8WX-2170-011 = 24V DC IP65 with emergency control by button 8WX-2270-051 = 24V DC IP57 II 2 G EEx m II T4 (Explosion Proof) 8WX-2270-041 = 24V DC IP67, without female connector

16 ASSEMBLY KIT:SEALS (VITON) AND SCREWS

DIMENSIONS / TIGHTENING TORQUES dimensions in millimeters (inches) MDM-5 **Dual Type** Single Type B,P: Ø6(0.2) T: Ø4(0.16) T: (34(0.16) 99.19 5 No. (6.4 to 9) A c 95 2549.81 SUBPLATE: A-5-DM M6 (4x or 6x), 9 (0.36) dp. 90(1:00) 80(31) b a C A-5-DM-1: 80(3.14) 30 (1,18) Connecting threads: P,T,A,B in BSP: 1/4" (standard) in SAE: SIZE 6 (optional) A-5-DM-2: 128(5.04) 78 (3,07) A-5-DM-3: 176(6.96) 126 (4.96) A-5-DM-4: 224(8.82) 174 (6.85) 222 (8.74) 270 (10.63) A-5-DM-5: 272(10.71) 126 (4.96) A-5-DM-6: 320(12.6) 126 (4.96) **CONVERSION PLATE: A-5-PS** Φ. 40(1.03)

MAINTENANCE DATA

Mounting procedure

- AMCA-valves shall not be mounted by overtightening of mounting bolts, causing mechanical distortion and thus spool lock.
- Mounting on flat surface, flatness 0,01/100.
- Don't use conical thread for port-fittings.
- For sealing purposes, use O-rings.
- Check the voltage and current of the solenoids, before operation.
- Avoid ingression of contaminants during mounting.

Start-up procedure

- Check the valve-function and thetightness of fittings etc.
- Bleed by repeated energizing of solenoid(s).
- Run the system to raise the fluid temperature.
 Rebleed to remove the dissolved air.

Adjustment procedure

Valve response time:

The valve response time is adjustable from ± 0.08 - 10 seconds.

Adjustment screws (damping throttles) are on the MDM-5 valve below the solenoids, fig 12 (1).

- Turn the adjustment screws clockwise to enlarge valve response time.
- Turn the adjustment screws anti-clockwise to shorten valve response time.

Fluid maintenance

Due to the construction, these AMCA-valves, are not highly susceptible to particulate (silt type) lock, nor to contaminant wear. Therefore the contaminant sensitivity is very low.

- Use mineral oil (recommended ISO/VG-32).
 Other fluids on request.
- Keep the contamination level better or equal NAS 1638 class 9 or ISO 18/15.

Damping throttle
 Spool
 Pistons

TROUBLE SHOOTING




FIG. 12

A. Valve operates erratically

- 1) Check the current on the solenoid plug.
- Air in system: Bleed by repeated energizing of solenoid(s). Run the system to raise the fluid temperature. Rebleed to remove the dissolved air.
- 3) Check the resistance of the solenoid coil:
 - 24 VDC at 20 °C (68 °F) = 25 Ohm, at 60 °C (140 °F) = 30 Ohm
 - 12 VDC at 20 °C (68 °F) = 6,5 Ohm, at 60 °C (140 °F) = 7,5 Ohm

B. Max. reducing pressure too low

- 1) Maximum current is faulty: check max. current.
- Supply pressure is too low: Check system pressure.

 Spool, pistons or solenoids are dirty: Remove solenoids or cover and clean solenoids' bore and spool (take care of the small pistons (3) in the spool (2) if placed, see fig.12).

C. System is too slow

- Damping throttles are closed too much: open up the throttles.
- 2) Electrical fault (ramp generator): check and reset.
- Damping throttle or spool are dirty: Remove the parts, 1, 2 and 3, clean everything and replace.

AMCA Hydraulic Fluid Power BV

B.Kuiperweg 33, 9792 PJ TEN POST P.O.BOX 18, 9790 AA TEN BOER The Netherlands

Tel.: +31 (0)50 - 3023577 Fax.: +31 (0)50 - 3021226 e-mail: sales@amca-nl.com

homepage: http://www.amca-nl.com

Your local representative	